NOW THE EASY PART...INSTALLATION

Congratulations on your purchase of the Terra Latch® product. You'll love the ease of installation and the compliments your new decorations generate.

Our rust-proof, stainless steel screws will work for most surfaces. Surfaces like wood, trees, stumps, lattice and any siding do not require anchors.

Remember, each Terra Latch® will support up to 90 lbs. and you never have to worry about them pulling out of the surface. It's all physics - gravity and leverage make it work. All the pressure is leaning against the bottom half of the latch.

On drywall, use the anchors that screw into that surface. Our screws go into the anchor.

SIDING: No need to find a stud. Use a small drill bit as lead hole. Our screws do the rest. No anchors necessary.

BRICK, STUCCO, CONCRETE, STONE:
Pre-drill using 1/4" masonry drill bit. Use TapCon screws into the mortar between the brick or stone. Use anchors with masonry screws on concrete or stucco,

WROUGHT IRON, CHAIN LINK, LATTICE:
No problem. Use 3-4 black self-locking nylon zip ties per Terra Latch®.

WINDOW BOXES:
Use TWO Terra Latches® for balance purposes. Remember, two can handle up to 180 lbs. For wrought iron baskets, turn the latch